High Speed Door Servo Control System

Contents

Introduction	2
Inspection	3
General Characteristic	3
Specifications	4
1. Specifications for Electronic Control System	4
2. Specifications for Motor	5
Operating Instructions	6
1. Basic Function	6
2. Control Key/Button	6
3. Install the stroke controller	7
4. Safety	7
Maintenance	8
Size	8
System Operation	12
Error Table	21
Port Table	22

Introduction

Thank you for choosing High Speed Door Servo Control System.

Please read this manual carefully before you start to use the system. In this manual you will find instructions for how to set the operating code the control unit, malfunction diagnostics and debugging, and routine maintenance.

Notice:

- > Before connecting the system to live wire place make sure the power supply is off.
- ➤ Please make sure the power voltage in the main circuit is the some as controller's rated voltage. Also please make sure the ground terminal is properly and reliably connect to the ground wire.
- > DO NOT touch output terminal directly. DO NOT shot circuit the output terminal and out shell.
- After the power supply is cut, and before the LCD is off, there still high voltage electricity in the circuit, so DO NOT touch the internal wiring and electronic components.
- ➤ Internal wiring and electronic components are very sensitivity to static electricity, so DO NOT let any object contact the internal wiring and electronic components of motor driver and the main circuit of the touch control panel.

Inspection

All product has passed inspection and testing before is leaving the factory.

When you open the unit place make sure there is no damager during shipping.

Also to confirm the equipment ratings are matching your requirement.

General Characteristic

Our servo control system is suitable for high speed PVC and aluminum doors.

The system is in compact package, with high torque and high operating speed, lower noise, high reliability, smooth and soft operating curves, it's suitable for high speed and intensive usage environment.

The rolling curtain can be controlled by wall switch, push button, bluetooth, radar, safety edge, photo eye, induction loops, etc.

Operating Speed: 0.5m/s-1.5m/s; Operating Width: < 16 m²/30 m²/60 m²; Daily operating time: 2000 time; Rated voltage: 220V; Rated Output: 0.75 KW/1.5KW/2.2KW

Specification

Specification for Electronic Control System

Model	PE200B	PE500B	PE700B
Rated Output Power	0.75KW	1.5KW	2.2KW
Supply Voltage	AC 220 V±10%	1	
Speed Control	Closed Loop Spee	ed Contrlol	
Position Control	Closed Loop Posi	tion Control	
Protective Function	Over-current Pro	otection, Over-vol	tage Protection,
	Under-voltage Pro	tection, Overheatin	g Protection and
	Overloading Protec	ction	
Installation Site	Indoor, away from direct sunlight, dust, corrosive gas,		
	oil and water vapor etc.		
Operation Temperature	-10℃~50℃		
Weight	5.8Kg	7.5Kg	8.7Kg
Installation Method	Wall Mounted		

Specification for Motor

Rated Output Power	0.75KW	1.5KW	2.2KW
Rated Speed	2,000 rpm	2,000 rpm	1,500 rpm
Rated Torque	3.6Nm	7.2Nm	15Nm
Heating	< 30°C	< 30°C	< 30°C
Working Temperature	-35℃-50℃	-35℃-50℃	-35℃-50℃
Torque Management System	Automatic Torque	Automatic Torque	Automatic Torque
Maximum Operating Width	< 16 m²	< 30 m²	< 60 m²
Limit Mode	Absolute Encoder	Absolute Encoder	Absolute Encoder
Self Locking Mode	Electro Mechanical Brake	Electro Mechanical Brake	Electro Mechanical Brake
Manual Release	Hand Crank	Hand Crank	Handle
Weight	4.9KG	8.1Kg	15.6Kg

Operating Instructions

1. Basic Function

The system can operated via: 1) control box; 2) inching electronic control; 3) continuous automatic operation; 4) emergency stop; 5) single side operation box; 6) time delay; 7) radar and/or induction loops. Please refer to wiring terminal for eternal connections.

System has fuse/safety wire shutdown switch for three-phase power protection, fuse/safety wire for operating circuit protection, and temperature sensing relay for motor protection.

2. Control Key/Button

- a) " † " Key/Button: Inching control door's opening movement or continuous automatic opening.
- b) " \(\text{" Key/Button: Inching control door's closing movement or continuous automatic closing.} \)

NOTE: these setting are set according to the contact; however they can be changed according to operating needs.

- c) "STOP" Key/Button: Push this key under emergency situation it will shutdown the operation and the door will stop and stay at that position
- d) Four key on LCD are main menu key.

3. Install the Stroke Controller

Stroke Controller utilizes absolute encoder. Connect the absolute encoder and reducer via encoder's axle, and fix the wings on to the reducer, than insert the aviation plug into plug receptacle.

4. Safety


- 1) The motor and control unit MUST ground properly;
- 2) During the installation, commission and operation **NO ONE** is permit to stand under the door and stand in the operating path;
- 3) While installing and testing the motor package, at least half of the door's axle
 MUST be insert into the reducer.
- 4) Check if there any obstacles in the operating path, if there is please remove the obstacles before lower the gate.
- 5) **DO NOT** disassemble the control unit; any damagers due to this action are **NOT** cover under free warranty.

The company reserves the right to modify the product, according to improvement of technology and production process, while the basic characteristic of the product may remain some.


Maintenance

The mounting screw for the control unit must inspect regularly to prevent screw been getting loose and falling off. Check the internal and external wirings. Check and change the oil for the redactor on regular basis.


Size




0.75KW Control Uint





1.5KW Control Unit




2.2KW Control Unit









0.75KW Motor






1.5KW Motor



2.2KW Motor



Absolute Encoder

High Speed Door Servo Control System
gp

System Operation



```
SERVO (dispaly)

MODE: (mode)

STATUS: (status)

Info Err Set Mode
```

(dispaly): Torque, Speed, Position.

(mode): Manual, Auto, Jog.

(status): OK, Opening, Closing, Falut, Stop, E-stop, Safty1, Safty2, Lock,


Maintenance.

----Mode

Press Mode key, input password (6668).



Change the operation mode (Manual, Auto, Jog).



----Set

Press Set key, input password (default 6668).



----1.Parameter

Index	Parameter	Value	Default
1	Opening Speed	10-125	100
2	Closing Speed	10-125	80
3	Open Slowdown dis.	30-70	50
4	Close Slowdown dis.	30-70	50
5	Auto Closing Time	Disable1-120 s	5 s
6	Output 1 Config	Non-close LimitClose LimitNon-open LimitOpen Limit	Disable
7	Output 2 Config	 Opening Closing Non-limit Position Limit Position 	Disable
8	Output 3 Config	Reach Close LimitFailure WarningDisable	Disable
9	Output 4 Config	 Double Interlock Automatic Opening Running Stopped Auto Mode State E-Stop State Auto Closing Countdown Delayed Opening Countdown 	Disable
10	Partial Opening	10-100%	100
11	Display Config	PositionSpeedTorque	Torque
12	Backlight Setting	60s OffAlways On	60s Off
13	Winter Autorun	Off1-999 min	Off

----2.Limit Switch Setting Select the limit switch type:

Option	Remaks
Mechanical Limit Switch	
Absolute Encoder	
Proximity Switch	
Incremental Encoder	Optional in debug mode

Limit Switch
Absolute Encoder

Adj Ok

Ensure the open direction.

Press OPEN-key
Direction
Correct?
Yes No


If limit switch is Proximity Switch, we shall find the Origin Position first.

Origin Position Lift the door Ecs

Origin Position
Reached
Ok Ecs

Next, we shall set the Open and Close Limit.

Open Limit
Ok Ecs



Finally, we will see the result.

Calibrate Programmed Ecs

or

Calibrate Failure Ecs

----3.RTC Config

Configure the date and time of the real time clock.

Year
 Month
 Day
 ↑ ↓ Ok
Esc

	Υ	'ear	
	2	015	
+	-	Save	Esc

Index	Parameter
1	Year
2	Month
3	Day
4	Hour
5	Minute


-----4.Advanced Setting


-----1. Communication

Set RS485 slave address and baudrate.

Slave Address
 Baud Rate
 ↑ ↓ Ok

Esc Slave Address 1 Save Esc + **Baud Rate** 4800 Save Esc Adj ----2.Contact Type Set the contact type. Index Parameter Default Value N.C 1 Ext E-Stop N.O / N.C 2 Safety1 N.O / N.C N.O 3 Safety2 N.O N.O / N.C 4 N.O / N.C N.O Auto Open 5 Partial Open N.O / N.C N.O 6 Start N.O / N.C N.O 7 Open Limit N.O / N.C N.O 8 Close Limit N.O N.O / N.C 9 N.O / N.C N.O Lock Input 1. Ext E-Stop Ext E-Stop 2. Safety1 N.O 3. Safety2 1 Ok Adj Save Esc Esc -3.Adv Parameter First, input password (7779). Password 7777 Ok Esc Select the parameter index. **Adv Parameter**





Index	Port	State
1	Manual Open	0: No Signal
2	Manual Close	1: Has Signal
3	Manual Stop	

4	Ext E-Stop
5	Safety 1
6	Safety 2
7	Auto Open
8	Partial Open
9	Start
10	Open Limit
11	Close Limit
12	Lock Input

-----2.Sum Counter
Displays the work cycles.

Sum Counter 88 Esc

----3.Maint Counter

Displays the work cycles after maintenance.

Maint Counter 88 Esc

-----4.Fault Memory
Displays the error history.

01. ERR23 No Limit Settings 2015-11-17 10:25

1 \downarrow Esc -----5.System Query Displays the value of selected system register. System Query 1 0 \downarrow Esc -----6.Version Displays the system version. ----7.RTC Query Displays the current date and time of the real time clock. **RTC Query** 2015-11-17 12:12:12 Esc ----Err Shows the current error message. **ERR 19** Absolute Encoder Failure

Esc

High Speed Door Servo Control System

Error Table:

Error Code	Content
ERR01	Overcurrent
ERR03	Under Voltage
ERR04	Over Voltage
ERR05	Over Voltage
ERR06	Locked Rotor
ERR07	Out Of Limit Position
ERR08	EEPROM Failure
ERR09	Over Speed
ERR10	Motor Reversion
ERR11	Overload
ERR12	Sample Current Failure
ERR13	Motor Encoder Failure
ERR14	Initial Rotor Angle Failure
ERR15	Communication Failure

ERR18	Brake Circuit Failure	
ERR19	Absolute Encoder Failure	
ERR20	Run Time Exceeded	
ERR21	Safety 1 Exceeded During Cycle	
ERR22	Safety 2 Exceeded During Cycle	
ERR23	No Limit Settings	
ERR24	DC24V Failure	
ERR26	Mechanical Limit Failure	
ERR27	Overheated	
ERR28	Electromagnetic Brake Fault	
ERR29	Absolute Encoder Reset	
ERR30	Motor Parameter Matching Fault	
ERR31	Motor Encoder Failure 2	
ERR32	Motor Encoder Failure 3	
ERR33	Absolute Encoder Failure 2	
ERR34	Absolute Encoder Reset 2	

ERR35	Absolute Encoder Run Reset	
ERR36	Limit Distance Too Short	
ERR38	Electromagnetic Brake Fault 2	
ERR39	Motor Encoder Failure 4	
ERR40	Motor Encoder Failure 5	

0.75KW

Port Table

Port	Function	Remark
1	PE	
2	L	AC220V input
3	N	
4	Braking resistor output +	
5	Braking resistor output	
6	Motor brake +	
7	Motor brake -	DC 96V
8	Com/Gnd	
9	Manual open input	NO
10	Manual close input	NO
11	Manual stop input	NO
12	Emergency stop input	NC
13	DC24V+	

14	Com/Gnd	
15	Safety input 1	NO (Safety edge, photocell, etc.), stop
16	Safety input 2	NO (Safety edge, photocell, etc.), reverse to open limit when closing
17	Automatic open input	NO
18	Partial open input	NO
19	Com/Gnd	
20	Start input	NO
21	Open limit switch input	NO
22	Close limit switch input	NO
23	Lock input	NO
24	DC24V+	
25	Com/Gnd	
26	Output 1A	1A-1B normally open, set the function selection "Output 1 Config" 1A-1B is closed
27	Output 1B	
28	Output 2A	2A-2B normally open, setting "Output 2 Config"
29	Output 2B	Function selection 2A-2B is closed

30	RS485+	
31	RS485-	

1.5KW&2.2KW

Port Table

Port	Function	Remark
1	PE	
2	N	AC220V input
3	L	
4	Braking resistor output -	
5	Braking resistor output +	
6	Motor brake -	DO 0.41/
7	Motor brake +	DC 24V
8	Reserved	
9	Safety input 1	NO (Safety edge, photocell, etc.), stop
10	Safety input 2	NO (Safety edge, photocell, etc.), reverse to open limit when closing
11	Com/Gnd	
12	DC24V+	
13	Automatic open input	NO (contact radar, and the sense)

14	Partial open input	NO
15	Start input	NO
16	Com/Gnd	
17	Open limit switch input	NO
18	Close limit switch input	NO
19	Lock input	NO
20	Com/Gnd	
21	DC24V+	
22	Output 1A	1A-1B normally open, set the function selection
23	Output 1B	"Output 1 Config" 1A-1B is closed
24	Output 2A	2A-2B normally open, setting "Output 2 Config"
25	Output 2B	Function selection 2A-2B is closed
26	Output 3A	3A-3B normally open, set the function selection
27	Output 3B	"Output 3 Config" 3A-3B is closed
28	Output 4A	4A-4B normally open, setting "Output 4 Config"
29	Output 4B	Function selection 4A-4B is closed

		,
30	RS485+	
31	RS485-	
32	Com/Gnd	
33	Manual open input	NO
34	Manual close input	NO
35	Manual stop input	NO
36	Emergency stop input	NC