




MURPHY DOOR™
CREATIVE DOOR SOLUTIONS

Mag-Lock with Biometric & Push Button Wiring Diagram



Quick Programming Guide

1. Open rubber access panel on bottom
2. Place remote close to scanner
(keys on remote will not beep if you are too far away)
- NOTE: The red light will flash to signify that it is ready to program. You will also hear an audible beep after each step. If you do not hear a beep it means that it did not complete the step properly.
3. Press *
(Red light will come on and stay solid)
4. Enter 1 2 3 4 5 6
5. Place finger on pad for 2 beeps
6. Take finger off and light will stay blue if successful
7. Press # to exit

At any point you may add additional users by following the same process of placing a finger on the pad for 2 beeps and then pressing # when done.