



[Disinfection Lamp Manual]

Disinfection Lamp

Product manual



SUITABLE PLACES

Bathroom, bedroom, bathroom, kitchen, lobby

Thanks for your purchase! Image shown here is for illustration purposes only, actual product may vary. (Please read this manual carefully before using the device, and keep it for future reference.)

The Disinfection lamp achieves the purpose of sterilization by targeting the DNA of microbes, damaging the DNA structure and preventing their reproduction. It kills *Candida albicans*, *Staphylococcus aureus* and *Escherichia coli*, and other germs and viruses. This device provides sterilization and air purification for kitchen, bedroom, bathroom, toilet, shoe cabinet, wardrobe, and other small space.

I :Specification

Product name: Disinfection Lamp	Product dimension: 56*56*125mm
Model: LYL-KQXDJ-UV-04	Package dimension: 7.6*7.6*14.8cm
Rated voltage: DC 3.7v	Timer options: button for 30 minutes lighting
Rated power: 3.8w	UV tube serving time: 30000H
Charging voltage: DC 5.0v	

II:How to use

- 1.Long press the power button for 3 seconds, light will be switched on after a delay of 28 seconds. The blue delay indicate light will be flashing during the 28 seconds, after which lamp will start working and the indicate light will be turned on. The disinfection lamp will turn off automatically after 30 minutes.
- 2.When the lamp is working, short press the power button will turn off light immediately.

III How to charge

- 1.This device is powered by rechargeable 3.7v lithium battery, and can be charged by regular phone charger;
- 2.During charging, the color of indicate light will be red, and it turns green when fully charged;
- 3.Approximately 120 minutes required for the battery to be fully charged in a single cycle.

[Special Warning]

- Do not look directly into the UV light source and use the device in the absence of people, animals and plants as the UV light may cause rash, conjunctival irritation, fatigue and so on.
- Long time exposure to UV light has the potential hazard of skin and eye burning, long time inhaling ozone can damage the respiratory tract. Please close doors and windows during the sterilization, and no people or animals should be staying in the same room.

(Attention: No people, animals or plants should be present while the ultraviolet germicidal lamp is working! Direct exposure to UV radiation may cause skin and eye damage.)

[Disinfection Lamp Manual]

The Disinfection lamp achieves the purpose of sterilization by targeting the DNA of microbes, damaging the DNA structure and preventing their reproduction. It kills *Candida albicans*, *Staphylococcus aureus* and *Escherichia coli*, and other germs and viruses. This device provides sterilization and air purification for kitchen, bedroom, bathroom, toilet, shoe cabinet, wardrobe, and other small space.

I :Specification

Product name: Disinfection Lamp	Product dimension: 56*56*125mm
Model: LYL-KQXDJ-UV-04	Package dimension: 7.6*7.6*14.8cm
Rated voltage: DC 3.7v	Timer options: button for 30 minutes lighting
Rated power: 3.8w	UV tube serving time: 30000H
Charging voltage: DC 5.0v	

II:How to use

- 1.Long press the power button for 3 seconds, light will be switched on after a delay of 28 seconds. The blue delay indicate light will be flashing during the 28 seconds, after which lamp will start working and the indicate light will be turned on. The disinfection lamp will turn off automatically after 30 minutes.
- 2.When the lamp is working, short press the power button will turn off light immediately.

III How to charge

- 1.This device is powered by rechargeable 3.7v lithium battery, and can be charged by regular phone charger;
- 2.During charging, the color of indicate light will be red, and it turns green when fully charged;
- 3.Approximately 120 minutes required for the battery to be fully charged in a single cycle.

[Special Warning]

- Do not look directly into the UV light source and use the device in the absence of people, animals and plants as the UV light may cause rash, conjunctival irritation, fatigue and so on.
- Long time exposure to UV light has the potential hazard of skin and eye burning, long time inhaling ozone can damage the respiratory tract. Please close doors and windows during the sterilization, and no people or animals should be staying in the same room.

(Attention: No people, animals or plants should be present while the ultraviolet germicidal lamp is working! Direct exposure to UV radiation may cause skin and eye damage.)

[After-sales Services]

Dear customer, thanks for purchasing and using our products. According to national warranty regulations, after receiving the product, the whole product is covered by 1-year free warranty in the presence of a valid receipt. The service commitments are:

- 1.Upon a defective under normal use, consumers can get free repair service by providing the warranty card or invoice, unless it is an artificial damage.
- 2.The warranty period is 1 year for the lamp body. The life span of the light tube is approximately 30000 hours, it is recommended to purchase the original tube for a guarantee of the lifetime and effectiveness.
- 3.Following circumstances are not covered by warranty, but repair service can be provided on charge:
 - a.Malfunction due to improper operations that not follow the instructions;
 - b.Damage due to improper storage, maintenance, usage or other factors;
 - c.Defective caused by unauthorized disassembly, modification to the device;
 - d.Use the household product in a non-home environment (e.g. production, business conduction, commercial usage);
 - e.Extreme or external causes beyond reasonable control including, but not limited to, thunder, fire, earthquake, flood and other majeure;
 - f.No receipt or purchase proof; Illegible writing or alteration on the receipts.
- 4.Please contact the local dealer or online customer service when a repair service is required. The sending and returning freight cost is charged on user.

[Warranty Card]

Product model (required): _____ Seller (store id): _____
Order id: _____ Purchase date: _____
User name/ID: _____ Contact phone: _____
Customer Address: _____
Service type: return ☐ exchange ☐ repair ☐
Return or exchange reason / issue description: